MODEL: 50720COP

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS FOUNTAIN SHOULD TAKE APPROXIMATELY 10 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

UNPACK THE FOUNTAIN

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS: COLUMN, POLE, RESERVOIR, BASE, (2) LED CLUSTERS, LIGHT CORD, PUMP AND TRANSFORMER.

FOUNTAIN ASSEMBLY

1. FEED PUMP POWER CORD TOWARD BOTTOM OF BASE, CORD EXIT OUT FROM CHANNEL ON THE BOTTOM OF THE BASE.

2. PLACE RESERVOIR ONTO TOP OF THE BASE AT NOTCHES.



3. PLACE POLE INTO RESERVOIR AT NOTCHES.



4. PLACE (2) LED CLUSTERS INTO THE (2) LED CLUSTER HOLDERS.



MODEL: 50720COP

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

FOUNTAIN ASSEMBLY

5. JOIN LIGHT CONNECTORS AND SCREW THE CAPS TO CONNECTORS TIGHTLY TOGETHER.



6. JOIN CONNECTORS AND SCREW THE CAPS TO CONNECTORS TIGHTLY TOGETHER.

7. ATTACH PUMP TO RUBBER HOSE.

8. PLACE COLUMN ONTO TOP OF POLE AT NOTCHES.



9. FILL RESERVOIR WITH 3.6 GALLONS OF WATER TO COMPLETELY SUBMERSE THE PUMP.

NOTE: DISTILLED WATER IS RECOMMENDED TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD-UP.



10. JOIN CONNECTORS AT TRANSFORMER AND SCREW THE CAP TO CONNECTOR TIGHTLY TOGETHER.

11. PLUG TRANSFORMER INTO OUTLET, THEN TEST WATER RUNNING, ADJUST THE WATER VALVE ON PUMP IF NEEDED.

12. YOUR NEW FOUNTAIN IS READY FOR USE.

AVAILABLE PARTS ARE:
BULB3009 (BULB)
PUMP1034 (PUMP)
TRANS2017 (TRANSFORMER)

TROUBLE SHOOTING:

1. IF YOUR FOUNTAIN DOES NOT WORK, CHECK PLUG AT THE SOCKET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE WALL OUTLET.

2. NEXT CHECK TO MAKE SURE THE OUTLET IS POWERED.

3. IF THE FOUNTAIN STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

SPLASHING DISCLAIMER:

SPLASHING MAY OCCUR WHEN FOUNTAIN IS INITIALLY TURNED ON. PROTECT SURROUNDING SURFACES AS NEEDED.

IMPORTANT PUMP INFORMATION:

PUMP MUST BE FULLY SUBMERSED IN WATER WHILE OPERATING.

WATER:

TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP THE USE OF DISTILLED WATER IS RECOMMENDED.

WARNING:

* ONCE A WEEK INSPECT FOUNTAIN, FLOOR AND ADJACENT WALL FOR MOISTURE BUILD–UP AND CLEAN AS NECESSARY. THIS IS ESPECIALLY IMPORTANT FOR HUMID ENVIRONMENTS.

** THIS FOUNTAIN IS RATED FOR OUTDOOR USE.

*** THIS UNIT MUST BE CONNECTED TO A SUPPLY CIRCUIT THAT IS PROTECTED BY A GROUND FAULT CIRCUIT INTERRUPTER (GFCI). THE GFCI SHOULD BE TESTED ON A ROUTINE BASIS. TO TEST THE GFCI, PUSH THE TEST BUTTON. THE GFCI SHOULD INTERRUPT POWER. PUSH THE RESET BUTTON. POWER SHOULD BE RESTORED. IF THE GFCI FAILS TO OPERATE IN THIS MANNER, THE GFCI IS DEFECTIVE.



PUMP REPLACEMENT:

1. UNPLUG THE FOUNTAIN.

2. DISASSEMBLE THE FOUNTAIN AS NECESSARY TO EXPOSE RESERVOIR.

3. REMOVE ALL WATER FROM RESERVOIR.

4. SNIP THE PLASTIC TIE STRIP.

5. PEEL BACK RUBBER GASKET FROM PLASTIC TUBE.

6. PULL OUT OLD PUMP FROM FOUNTAIN.

7. THREAD CORD FOR NEW PUMP THROUGH PLASTIC TUBE.

8. PLACE RUBBER GASKET OVER PLASTIC TUBE AND SECURE BY TIGHTENING A NEW PLASTIC TIE STRIP.

9. REASSEMBLE THE FOUNTAIN WITH NEW PUMP.